CANFORD HEADPHONE AND HEADSET SPARE PARTS - 200 Series

1	Ear loudspeaker, 400 ohms for <u>DMH205</u> /220/225, SMH210	<u>27-801</u>	
1	Ear loudspeaker, 300 ohms (for <u>DMH285</u> only)	<u>27-800</u>	
2	Mic capsule, dynamic, 200 ohms	<u>27-802</u>	6
3	Cable bush	<u>27-803</u>	
4	Cable ring, brass	<u>27-804</u>	
5	Steel cable, straight (standard)	<u>27-805</u>	12
6	Headband cushion (DMH220, 225, 205, 285)	<u>27-806</u>	7 31
6	Headband cushion (SMH210)	<u>27-837</u>	8 16, 17
7	Headband holder – outer	<u>27-807</u>	13
8	Headband holder – inner	<u>27-808</u>	4
9	Screw, M2.2 ×9.5 csk	<u>27-809</u>	14 18
10	Screw, M2.2 ×6.5 csk	<u>27-810</u>	
11	Headband, spring steel bow	<u>27-811</u>	30 27
12	Earphone cable	<u>27-812</u>	15
13	Bellows	<u>27-813</u>	
14	Housing (left) (SMH210, DMH220, DMH225)	<u>27-814</u>	
14	Housing (left) (DMH205, DMH285)	<u>27-838</u>	/ / /
15	Housing (right) (DMH220, DMH225, DMH205, DMH285)	<u>27-815</u>	29 5
16	Sliding part, headband	<u>27-816</u>	28
17	Washer	<u>27-817</u>	
18	Mic boom cable	<u>27-818</u>	/ / 21
19	Wire insert, mic boom	<u>27-819</u>	2^{2} 2^{2}
21	Mic housing, lower part	<u>27-821</u>	25
22	Mic housing, dynamic, upper part	<u>27-866</u>	distributed by
23	Mic housing, sleeve	<u>27-823</u>	CANFORD



CANFORD HEADPHONE AND HEADSET SPARE PARTS - 200 Series

25	Mic system, felt washer	<u>27-825</u>
27	Protective cloth for ear loudspeaker	<u>27-827</u>
28	Circumaural earpad (Left side SMH210, DMH220/225)	<u>27-849</u>
29	Circumaural earpad (Right side DMH220/225, both sides DMH205/285)	<u>27-840</u>
28	Supra-aural earpad (Left side SMH210, DMH220/225)	<u>27-828</u>
29	Supra-aural earpad (Right side DMH220/225, both sides DMH205/285)	<u>27-829</u>
28/29	Heavy-duty earpad (all models)	<u>27-839</u>
30	Clip insert	<u>27-830</u>
31	Screw, M2.2 ×9.5 csk	<u>27-809</u>
-	Foam pad holder (SMH210)	27-834
_	Foam pad (SMH210)	27-835



